Advanced Paging Productivity Pack Quick Reference

Business Communications Manager

You can download all documents referenced in this document at www.nortel.com.

Downloading the APPP software update

From the Nortel Technical Support Web site (www.nortel.com/support), download the APPP software update.

Installing the APPP software update

With Element Manager or Network Configuration Manager (NCM), install the APPP software update:

- From the Element Manager navigation panel, select **Administration > Software Management > Software Updates**.
  For more information about performing software updates with Element Manager, see the *Administration Guide* for your BCM system.
- From the NCM navigation panel, select **Administration > Configuration Data**, and then select your BCM systems.
  For more information about performing software updates with NCM, see the *Using NCM to Manage BCM* document for your BCM system.

Applying the APPP keycode

1. Using the Nortel Keycode Retrieval System (KRS) and your APPP authorization code, generate the new keycode file for each BCM system to update.
2. With Element Manager or NCM, apply the APPP keycode file:
   - From the Element Manager navigation panel, select **Configuration > System > Keycodes**.
     For more information about applying keycodes with Element Manager, see the *Keycode Installation Guide* (NN40010-301).
   - From the NCM navigation panel, select **Administration > Configuration Data > Wizards tab > Keycode Wizard**.
     For more information about applying keycodes with NCM, see the *Using NCM to Manage BCM* document for your BCM system.

Configuring the APPP features

Configure the APPP features with Element Manager, NCM, or CallPilot Manager. For more information, see *Advanced Paging Productivity Pack Configuration* (NN40010-503).

NN40010-504
N0156528 01.01
July 2007
Copyright Nortel Networks 2007
All Rights Reserved.